



| GENERAL TELEVISION FREQUENCIES | |
|--|----------------|
| Sub CATV Band - T7 - T13 | 7 - 58 Mhz |
| VHF Band - Ch. 2 - 13 | 54 - 216 Mhz |
| Low Band - VHF Ch. 2 - 6 | 59 - 88 Mhz |
| Mid Band - UHF Ch. 14 - 22 | 121 - 174 Mhz |
| - UHF Ch. 95 - 99 | 91 - 120 Mhz |
| High Band - VHF Ch. 7 - 13 | 175 - 216 Mhz |
| Super Band - CATV Ch. 23 - 36 | 216 - 300 Mhz |
| Hyper Band - CATV Ch. 37 - 62 | 300 - 456 Mhz |
| Ultra Band - CATV Ch. 63 - 158 | 457 - 1002 Mhz |
| UHF Band Ch.14 - 83 - CATV Ch. 63 - 158 | 70 - 1002 Mhz |