



VHF AND UHF CHANNELS WITH RELATED FREQUENCY

VHF TELEVISION		
BAND	CH #	FREQUENCY
VHF LOW	2	54-60 Mhz
VHF LOW	3	60-66 Mhz
VHF LOW	4	66-72 Mhz
VHF LOW	5	76-82 Mhz
VHF LOW	6	82-88 Mhz
VHF HIGH	7	174-180 Mhz
VHF HIGH	8	180-186 Mhz
VHF HIGH	9	186-192 Mhz
VHF HIGH	10	192-198 Mhz
VHF HIGH	11	198-204 Mhz
VHF HIGH	12	204-210 Mhz
VHF HIGH	13	210-216 Mhz

UHF TELEVISION					
CH #	FREQUENCY	CH #	FREQUENCY	CH #	FREQUENCY
14	470-476 Mhz	43	644-650 Mhz	72	818-824 Mhz
15	476-482 Mhz	44	650-656 Mhz	73	824-830 Mhz
16	482-488 Mhz	45	656-662 Mhz	74	830-836 Mhz
17	488-494 Mhz	46	662-668 Mhz	75	836-842 Mhz
18	494-500 Mhz	47	668-674 Mhz	76	842-848 Mhz
19	500-506 Mhz	48	674-680 Mhz	77	848-854 Mhz
20	506-512 Mhz	49	680-686 Mhz	78	854-860 Mhz
21	512-518 Mhz	50	686-692 Mhz	79	860-866 Mhz
22	518-524 Mhz	51	692-698 Mhz	80	866-872 Mhz
23	524-530 Mhz	52	698-704 Mhz	81	872-878 Mhz
24	530-536 Mhz	53	704-710 Mhz	82	878-884 Mhz
25	536-542 Mhz	54	710-716 Mhz	83	884-890 Mhz
26	542-548 Mhz	55	716-722 Mhz		
27	548-554 Mhz	56	722-728 Mhz		
28	554-560 Mhz	57	728-734 Mhz		
29	560-566 Mhz	58	734-740 Mhz		
30	566-572 Mhz	59	740-746 Mhz		
31	572-578 Mhz	60	746-752 Mhz		
32	578-584 Mhz	61	752-758 Mhz		
33	584-590 Mhz	62	758-764 Mhz		
34	590-596 Mhz	63	764-770 Mhz		
35	596-602 Mhz	64	770-776 Mhz		
36	602-608 Mhz	65	776-782 Mhz		
37	608-614 Mhz	66	782-788 Mhz		
38	614-620 Mhz	67	788-794 Mhz		
39	620-626 Mhz	68	794-800 Mhz		
40	626-632 Mhz	69	800-806 Mhz		
41	632-638 Mhz	70	806-812 Mhz		
42	638-644 Mhz	71	812-818 Mhz		

